

Instruction Sheet

Front Control Arm Link Bracket

Z5374

Note: this bracket is required for AU series cars with threaded style front swaybar link.

Application:

Ford Falcon AU models to - 2/00.

Contents (per arm):

1 x Swaybar bracket.

1 x M10 bolt + spring washer.

1 x M6 bolt + spring washer.

N.B: This instruction sheet should be used in conjunction with the workshop manual



1. Confirm contents and hardware including spring washers are correctly supplied - refer Fig 1.
2. Bolt the bracket to the arm as per Fig 4 - start both bolts with spring washers prior to tightening - refer Figures 2 and 3..



3. Tighten the M10 bolt first to approx. 35-40Nm. Followed by the smaller M6 to approx. 5-6Nm
4. Re-check all bolts after road test.

N.B: It is recommended that a licenced workshop or tradesperson carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.