

## STABILISER BARS

### General Fitting Instructions;

Code: 10

When fitting sway bars be sure to follow the procedures set out in the instruction sheets supplied with the bar. Pay particular attention to tensioning link bush nuts as it is critical that they are not tightened to the point that they distort the bush.

PLEASE DRIVE CAREFULLY AND ACCUSTOM YOURSELF TO THE FLATTER RIDE AND IMPROVED HANDLING CHARACTERISTICS OF YOUR VEHICLE.

#### Specific Instructions For This Bar

The LH Torana already has mounting points in the lower control arm for the swaybar link pins.

1. The swaybar mounts behind the engine (approx. under the bell housing). The arms face forward and above the lower wishbone.
2. Assemble the links to the wishbone as shown in diagram below. Then attach the swaybar to the links and wishbone.
3. Using the smaller bolts supplied assemble the saddles, D-bushes and brackets as shown in diagram below. Do not tighten nuts at this stage. Raise the back of the swaybar so that the brackets are next to the sub-frame. Ensuring that the top of the links are approx 12mm rearward of vertical mark and drill the sub-frame for the chassis brackets.
4. Bolts the chassis brackets to the sub-frame and tighten all bolts. Do not over tighten the link bushes.

