

Fitting Instructions

REAR SWAYBAR KIT

Code: Z5265

Application:

HOLDEN CRUZE:

2012 - ON

Always refer to current catalogue for complete application listing.

Kit Contents:

1 x 22mm swaybar.
2 x threaded boss.
2 x 10.9 class bolts.
2 x flat washers.

- Raise vehicle evenly and safely support.
- Using a suitable jack stand, support the rear axle beam and undo the lower shock bolts.
- Once the lower bolts have been removed, lower the beam down and remove the rear coils.
- Remove the lower rubber spring pad.
- Remove the lower spring locator with a suitable punch (refer below images).
- Position supplied threaded boss in spring seat.



Unbolt lower shock mount and remove coils.



Punch out spring locator



Position supplied threaded boss.

N.B: It is recommended that a licenced workshop or tradesperson carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.

Fitting Instructions

REAR SWAYBAR KIT

Code: Z5265

Application:

HOLDEN CRUZE:

2012 - ON

Always refer to current catalogue for complete application listing.

Kit Contents:

1 x 22mm swaybar.
2 x threaded boss.
2 x 10.9 class bolts.
2 x flat washers.

- Refit rubber spring pads and coils.
- Confirm threaded boss is properly located.
- Using a suitable jack, raise the rear beam and bolt up lower shock mount.
- Bolt the swaybar into position using the supplied bolts and washers.
- We suggest using a small amount of Loctite to the threads before tightening.
- Re check bolts after initial 100kms driven.



Re fit spring pads and coils



Confirm threaded boss is properly located.

